



2





FIGURE 3



FIGURE

3A




FIGURE 4




FIGURE 5






FIGURE 6



131

FIGURE 7

Temp. Selector  
Disk Housing  
cover



Mounting Flange

65

67

106

120

66

121

91'



FIGURE

8




FIGURE 9

.Mid Assembly Cross Over Insert





FIGURE 10



10: On/Off Control Shaft




FIGURE 12





FIGURE 1/3






FIGURE 14



Nozzle Housing



Nozzle Base

Nozzle Head

413

FIGURE 15









FIGURE 15

Bracket Assembly Bottom




Hose Access Panel



Nut

Seat Bolt wing



Control Unit Housing Top




FIGURE 17

On/Off Dial

